



Revised  
1.5.06

2360 Boswell Road  
Chula Vista, CA 91914  
Phone 619.216.1444  
Fax 619.216.1474  
E-Mail tech@explorerprocomp.com

## PRO COMP SUSPENSION

Suspension Systems that Work!

### SUPPLEMENTAL INSTRUCTIONS:

**PART# 90-6438**  
**Spare Tire Guide**  
**Bracket**  
**Installation Kit**

Part #	Bill Of Materials Description	Qty.
90-6299	<b>HARDWARE PACK: Spare Tire</b>	2
70-0311001500	5/16" X 1" GR. 5 HEXBOLT	2
72-03100100512	5/16" NYLOCK NUT	2
73-03100030	5/16" SAE FLAT WASHER	4
90-3326	<b>SPARE TIRE ADAPTER BRACKET</b>	1

### INSTRUCTIONS:

1. Secure the spare tire adapter bracket (**90-3326**) to the driver side rear drop support arm (**90-3233**) holes using the supplied **3/8" X 2 3/4"** bolts from the lift kit **59005**. See Illustration 1.
2. Reinstall the factory spare tire guide to the spare tire adapter bracket (**90-3326**) and secure with the supplied **5/16" X 1"** bolts and hardware See ILLUSTRATION 1.

